

# FORMAX<sup>®</sup>

---

FD 1502Plus AutoSeal<sup>®</sup>




# TABLE OF CONTENTS



<b>TOPIC</b>	<b>PAGE</b>
DESCRIPTION	1
SPECIFICATIONS	1
UNPACKING AND SET-UP	2
CONTROL PANEL	3
OPERATION	3
FOLD PLATE ADJUSTMENT	4 - 5
SETTING CUSTOM FOLDS	5
DAILY MAINTENANCE	6
TROUBLESHOOTING	6 - 7
INSTALLING OPTIONAL FLOW STRAPS	8
DETERMINING FOLD TYPE	9
TEST SHEET	10



# **DESCRIPTION**



## **FUNCTION:**

The 1502Plus Pressure Sealer folds and seals many different configurations, including “C”, “Z”, “V” and custom folds. It also accommodates several different sizes of forms. For configurations and/or paper sizes specifications below.

Paper size:	8.5” W x 14” L
Fold styles:	C, Z, V uneven Z, uneven C, custom folds
Fixed speed:	Up to 6,250 sheets per hour
Hopper capacity:	Up to 200 sheets 20#
Weight:	90 lbs.
Dimensions:	37” L x 17” W x 13” H
Power supply:	120V, 50/60 Hz
Certifications:	UL Approved


## **UNPACKING & SET-UP**

1. Check package for shipping damage. If there is shipping damage, do not discard the box.

2. CAUTION: Two people are required to lift the machine out of the box.

3. Place the jam clearing handle into the the holder which is mounted to the machine. This is the jam clearing tool’s proper location (see picture, right).

4. Install upper fold plate (refer to pages 4 and 5 for proper installation).



## UNPACKING AND SET UP, continued

5. To attach the conveyor to the out-feed, align the tab on the right side of the conveyor with the slot on the machine (Figure 1a). Rest the support braces on the two alignment studs (see arrows), and tighten the four thumbscrews provided (Figure 1b).




Figure 1a




Figure 1b

3. Install outfeed wheels (Fig. 1c) by inserting the right side (spring loaded) into the right side of the body, just above the conveyor (Fig 1d), then insert the left end of the outfeed wheel crossbar into the left side.

4. Plug cord into machine and into wall outlet.




Figure 1c

Spring-loaded end





Figure 1d



# CONTROL PANEL

1	Start	Starts machine operation
2	Stop	Stops machine operation
3	Ready Light	- Steady green when power is on - Blinks red when cover is open or fault is detected
4	Counter	Displays number of forms processed
5	Counter Reset	Resets Counter



# OPERATION

1. Adjust fold plates to desired fold for length of paper (see fold plate adjustment on page 4). To do this, loosen the two thumbscrews (Figure 4a & b) on each fold plate. Align center bar (Figure 4a & b) so the marks on each side match up. For “V” folds, remove the lower fold plate, turn around 180° and reinstall.
2. Make sure fold plates and cover are reinstalled properly.
3. Plug in cord and turn power on (Figure 2).
4. To make sure folds are in the correct location, push the paper feed lever (Figure 3) down and place one form onto the in-feed table and press the start button. Adjust fold plates if necessary (see fold plate adjustment on page 4).
5. Push the paper feed lever down and load paper neatly stacked and squared onto the in-feed table. Paper can be stacked up to 150 sheets. **Note:** Standard “Z” fold forms can be loaded face up or down with the glue edge leading. All “C” fold forms must be loaded face up with glue edge leading.
6. Be sure the ready light is green and press the start button to begin operation.




Figure 2

Power Switch





Figure 3

Paper Feed Lever

# FOLD PLATE ADJUSTMENT



1. To adjust the first fold remove the top cover to access the top fold plate. If the first fold is too long loosen the two thumbscrews on the upper fold plate and slide the bar down. If the fold is too short loosen the thumbscrews and slide the bar up.

**NOTE:** The bar should be on the same marks on each side.

2. To adjust the second fold remove the lower fold plate. If the second fold is too long loosen the two thumbscrews and slide the bar up. If the fold is too short loosen the thumbscrews and slide the bar down.

**NOTE:** The bar should be on the same marks on each side.

3. For quick setup of “C”, “Z” , Uneven “C” and “V” folds refer to the blue lines on the fold plate.

4. To reinstall the upper fold plate, slide the plate (with thumbscrews facing up and the throat toward the inside of the machine) until the grooves on the underside line up with the four pins on the machine (Figure 4a & 4b).




Figure 4a

Fold Plate Pins




Figure 4b, correctly installed



5. To reinstall the lower fold plate, slide the plate (with the thumbscrews facing up and throat toward inside of machine, figure 5b) until it rests on the two silver bars (figure 5a) and locks into place (figure 5c).




Figure 5a

Bars




Figure 5b





Figure 5c

## SETTING CUSTOM FOLDS


### **Eccentric “Z”**

1. Measure the length of panel “A”.
2. Adjust the upper fold plate so that the bar lines up with the measurements of panel “A”, for example: if panel “A” is 5 1/4” long move the bar up or down so that it lines up with the 5 1/4” mark on the fold plate.
3. Measure the length of panel “B”.
4. Adjust the lower fold plate so that the bar lines up with the measurements of panel “B”.
5. Load forms and press start (refer to OPERATION on page 3).



### **Uneven “C” / Return Mailer**

1. Measure the length of panel “A” & “B”.
2. Adjust the upper fold plate so that the bar lines up with the measurements of panel “A” & “B”, for example: if panel “A” + “B” is 10 1/2” long move the bar up or down so that it lines up with the 10 1/2” mark on the fold plate.
3. Measure the length of panel “B”.
4. Adjust the lower fold plate so that the bar lines up with the measurements of panel “B”.
5. Load forms and press start (refer to OPERATION on page 3).



## DAILY MAINTENANCE

1. It is recommended to let forms cool for one-half hour, from the laser printer, before folding and sealing. This allows toner to set on the forms, and static electricity to discharge. A 402 Series Jogger is recommended for best results. The Jogger squares the forms and dissipates heat and static electricity created by laser printers.
2. If toner builds up on the metal sealer rollers, clean the rollers with a lint-free cloth dampened sparingly with a mild household cleaner.
3. Clean in-feed wheels and fold rollers with Formax-recommended roller cleaner & rejuvenator (Formax part #203) to remove paper dust and toner. A damp cloth with water is the best alternative. **CAUTION:** Do not use any chemicals other than the roller cleaner & rejuvenator or water.

## TROUBLESHOOTING

### **A. Clearing Paper Jams:**

**WARNING:** Turn machine off and unplug cord from its receptacle.

1. If a jam occurs between the metal rollers remove any remaining forms from the hopper.
2. Open the top cover and remove the upper fold plate.
3. Remove the jam clearing handle (located under the upper fold table), apply the handle to the upper metal roller (figure 6) and turn clockwise until the paper jam is clear. **NOTE:** Do not turn the roller counter-clockwise to force the forms to exit: rollers may be damaged.
4. Remove the damaged form, return tool to holder and reinstall upper fold plate.
5. Reinstall cover and press the black reset button (figure 7).




Figure 6




Figure 7

If a jam occurs in the fold plates, remove fold plate and remove paper. Reinstall fold plate.

# **TROUBLESHOOTING**

## **B. Fold Quality Needs Improving:**

1. Make sure paper is squared and installed correctly. Side guides should be evenly balanced and snug against the paper.
2. If folds are still incorrect adjust fold plates (see fold plate adjustment on page 3).

## **C. Paper is not Folding Square (Skewing):**



Figure 8

1. If paper pulls left or right adjust the skew. Turn the skew adjuster, located under the infeed tray, (Fig. 8) left or right until the paper is feeding correctly.

## **D. Ready light is not illuminated and power is on:**

1. Press the black circuit breaker button (Fig. 7) near the power cord inlet to reset the breaker.

## **E. Ready light is blinking red:**

1. Check to see that the top cover is installed properly.
2. Check that the photo-eye, located before the metal sealer rollers, is clear of forms and/or paper dust.
3. Check for paper jam. If paper is jammed, refer to instructions on page 9.
4. Motor may be overheated

# INSTALLING OPTIONAL FLOW STRAPS

1. Optional Flow Straps can be used when processing thicker paper stock. To install, fold over 1/2 inch of strap. (Figure 19).

2. Place strap over static brush in appropriate location. (Figure 10)

**NOTE:** Straps should not be placed where they will interfere with the conveyor belts or the weighted out-feed tires, (see Figure 13).



Figure 9



Figure 10

3. With strap in place, press clip down over strap. (Figure 11)

4. Figure 12 shows strap and clip in place.

**NOTE:** Clip must be removed before moving strap to a different location.




Figure 11




Figure 12

5. Repeat process on other side. Figure 13 shows two straps in place.






Figure 13




# DETERMINING FOLD TYPE

Two Standard Folds 11" "Z" & 11" "C"  
Refer to page 5 for custom fold setup.



11" "Z" Fold



11" "C" Fold


# Leading Edge



Make copies of this page on copy paper for fine tuning folds

## Instruction For Lining Up Folds

1. Place a stack of these sheets into the feeder and fold one (1) or two (2) sheets.



2. Take a folded sheet from the catch tray and lay it on top of a pressure seal form lining the leading edge of this sheet up with leading edge of the pressure seal form.




Fig. 16 "Z" fold Form

3. If the folds on this test sheet do not line up with the perforated folds on the form, the fold plates need to be adjusted up or down to make the folds line up. Refer to Fig. 16 for a "Z" fold and Fig. 17 for a "C" fold.

- If fold "A" on the test form is right of the perforation on the pressure seal form move the top fold plate stop up. If fold "A" is below move the top fold plate stop down.

- If fold "B" on the test form is right of the perforation on the pressure seal form move the bottom fold plate stop down. If fold "B" is to the left move the bottom fold plate stop up.




Fig. 17 "C" Fold Form